Installation Instructions for the Acer Monitor Drivers that are not Digitally Signed

In the event that the driver you have downloaded from the Acer web site is not digitally signed, please follow the steps below. Note: these instructions are for the AL2032 driver and will be similar for any non-digitally signed driver.

1.Click mouse right button and chose "Properties"



Downloaded from www.Manualslib.com manuals search engine

2/3. In Display Properties, choose Settings first - you can see the monitor is detected as a Plug and Play Monitor. Click "Advanced" to go to next step.



4/5.Click "Monitor" and check the "Properties"



Downloaded from www.Manualslib.com manuals search engine

6/7. Click "Driver" then "Update Driver..."



Downloaded from www.Manualslib.com manuals search engine

8/9. Hardware Update Wizard will pop up and ask you if windows can connect to Windows Update to search for software. Choose "No, not at this time" then click "Next>"


Hardware Update Wizard
Welcome to the Hardware Update Wizard
Windows will search for current and updated software by looking on your computer, on the hardware installation CD, or on the Windows Update Web site (with your permission).
Read our privacy policy
Can Windows connect to Windows Update to search for software?
Yes, this time only
Yes, now and every time I connect a device
No, not this time
8
Click Next to continue.
9
< Back
Next >
Cancel

10/11. Choose"Install from a list or specific location (Advanced)" and click “Next>”


Hardware Update Wizard
This wizard helps you install software for:
Plug and Play Monitor
If your hardware came with an installation CD or floppy disk, insert it now.
What do you want the wizard to do?
10
Install the software automatically (Recommended)
Install from a list or specific location (Advanced)
Click Next to continue.
11
Next >
Cancel

Downloaded from www.Manualslib.com manuals search engine

12/13.Choose "Don't search. I will choose the driver to install" and click "Next>".


Hardware Update Wizard
Please choose your search and installation options.
Search for the best driver in these locations.
Use the check boxes below to limit or expand the default search, which includes local paths and removable media. The best driver found will be installed.
Search removable media (floppy, CD-ROM...)
Include this location in the search:
12
C:\
Browse
Don't search. I will choose the driver to install.
Choose this option to select the device driver from a list. Windows does not guarantee that the driver you choose will be the best match for your hardware.
13
< Back
Next >
Cancel

14/15.Choose"Have Disk...." and click "Next>"


Hardware Update Wizard
Select the device driver you want to install for this hardware.
Select the manufacturer and model of your hardware device and then click Next. If you have a disk that contains the driver you want to install, click Have Disk.
Show compatible hardware
Model
Plug and Play Monitor
14
This driver is digitally signed.
Tell me why driver signing is important
Have Disk...
15
< Back
Next >
Cancel

Downloaded from www.Manualslib.com manuals search engine

16.Click "Browse..." to locate the files.



17/18. Link to folder "C:\AL2032W Driver" and find "07F0.inf", and Click "open".



Downloaded from www.Manualslib.com manuals search engine

19.Click "OK" to the next step.



20.You can see AL2032W driver found . Click "Next>"


Hardware Update Wizard
Select the device driver you want to install for this hardware.
Select the manufacturer and model of your hardware device and then click Next. If you have a disk that contains the driver you want to install, click Have Disk.
Show compatible hardware
Model
Acer AL2032W
This driver is not digitally signed!
Tell me why driver signing is important
Have Disk...
20
< Back
Next >
Cancel

Downloaded from www.Manualslib.com manuals search engine

21.During the installation , the system will warn you that this driver has not passed Windows Logo testing. Click "Continue Anyway" and it will start to install the driver files.


Hardware Installation
The software you are installing for this hardware:
Acer AL2032W
has not passed Windows Logo testing to verify its compatibility with Windows XP. (Tell me why this testing is important.)
Continuing your installation of this software may impair or destabilize the correct operation of your system either immediately or in the future. Microsoft strongly recommends that you stop this installation now and contact the hardware vendor for software that has passed Windows Logo testing.
21
Continue Anyway
STOP Installation
< Back
Next >
Cancel

22. After the files are copied , the installation is finished . Click "Finish" to close the installation.

Downloaded from www.Manualslib.com manuals search engine

23. In Display Properties , you can see AL2032W is installed and 1680x1050 resolution is selected.



Downloaded from www.Manualslib.com manuals search engine